



WONDERCAP

Tradelink
The Bathroom Specialist

Looking to buy a Wondercap? Head to your local Tradelink Store with your selected product's code!

WONDERCAP KITS - INSTALLED BEFORE CONCRETE



100mm Wondercap Kit
Wondercap Code: WC100K
Tradelink Code: 10332



80mm Wondercap Kit
Wondercap Code: WC80K
Tradelink Code: 10333



50mm Wondercap Kit
Wondercap Code: WC50K
Tradelink Code: 10334



WONDERCAP

Tradelink

The Bathroom Specialist

WONDERCAP KITS - INSTALLED BEFORE CONCRETE



50mm Wondercap Balcony Outlet Kit

Wondercap Code: WC50BOK

Tradelink Code: 114776



100mm Short Wondercap Kit

Wondercap Code: WC80K

Tradelink Code: 10335



WONDERCAP

Tradelink

The Bathroom Specialist

WONDERCAP RETRO KITS - INSTALLED AFTER CONCRETE



100mm Retro Kit

Wondercap Code: WC100RK

Tradelink Code: 104829



80mm Wondercap Kit

Wondercap Code: WC80RK

Tradelink Code: 104830



50mm Wondercap Kit

Wondercap Code: WC50RK

Tradelink Code: 104831



WONDERCAP

Tradelink
The Bathroom Specialist

WONDERCAP BASES



100mm Base & Cap

Wondercap Code: WC100

Tradelink Code: 10341



100mm Short Base & Cap

Wondercap Code: WC100S

Tradelink Code: 10937



80mm Base & Cap

Wondercap Code: WC80

Tradelink Code: 10326



50mm Base & Cap

Wondercap Code: WC50

Tradelink Code: 10342