



WONDERCAP

HDPE PIPE CONNECTION

For All Constructions



Installation of the Wondercap Drainage System Into HDPE Pipe

Step 1:

Clean and file smooth the internal HDPE pipe.

Step 2:

Apply heat with a heat gun or LPG map gas torch to a depth of 50mm to the internal pipe. **(DO NOT OVERHEAT OR MELT THE INTERNAL PIPE)**

Step 3:

The 100mm Kit and Retro Kit will easily push into the internal HDPE pipe.

Step 4:

Allow to cool and the Wondercap Drainage System connection to HDPE pipe is now joined tighter. The sealed connection can be water tested if required.

Note:

This sealed joining method is based on the product memory qualities of HDPE material. Used only for the final connection at the floor level for floor & shower waste grates only.



The Wondercap Drainage System can be installed into HDPE pipe

For more information visit
www.wondercap.com.au